



**MOTO
ARMOR**

CF Moto ZForce 950 Windshield Instructions

SKU: MA-ZF950-WS For: ZForce 950 Windshields (Not HO model)

Hardware Kit	
QTY	ITEM
4	Billet Hook Clamps Black
4	3/4" X 1/4-20 Black SS Bolts
4	1/4" Flat Washers Black SS
4	1/4" Lock Washers Black SS

Step 3. Bolt the windshield to the clamps using the $\frac{3}{4}$ " Bolts. Use a washer and lock washer on each bolt. Don't tighten the bolts until you have each one started in the clamps.

Step 4. Once each bolt has been started, tighten all the bolts until snug. Don't over tighten the bolts.

Step 1. Place the hook clamps on the roll cage in the approximate positions. They can be hard to put on so make sure to push them on all the way.

Step 2. Place the windshield on the machine and make sure the holes line up with the clamps.

